



PaveSaver™ Installation Guidelines

1. **Area Preparation** - Chip and/or saw all loose concrete, leaving only sound concrete. Carefully sandblast and blow out all areas which will be in contact with PaveSaver™.

2. **Mixing** - Mix 2000 ml (4.8 lbs) of Part A* and 2300 ml (4.8 lbs) of Part B* for 30-60 seconds. Add 2 pre-weighed 26.75 lb. bags of the aggregate blend and continue to mix. When properly mixed, PaveSaver™ is an even color.

* **Note:** Parts A and B volumes are different.

3. **Pouring** - Fill entire area to grade as you go - PaveSaver™ is self-leveling.

4. **Texturing** - As it cures, use a trowel to achieve a grooved or textured finish. Masking and forming materials which were used should be removed immediately after troweling.

5. **Equipment/Materials** - Use a grout mixer blade, 3/4" heavy duty drill and a 5 gallon pail (for mixing). One mix equals 4.4 mixed gallons.

Notes:

- Equipment and tools should be sprayed with silicone release agent prior to use.
- **Do not install** PaveSaver™ when any moisture is present or when pavement temperatures are below 50°F (10°C) or above 110°F.